


Check Your Transfer



"BASIC HUMMVVS ORIGINALLY HAD A MODEL 218 TRANSFER CASE, NSN 2520-01-163-4999.

THE MODEL 218 HAS A BOLT-ON FLANGE ON THE REAR PROPELLER SHAFT."



Model 218 transfer

"CONVERSION KIT, NSN 2520-01-434-0822, CONVERTS A BASIC VEHICLE WITH THE MODEL 218 TRANSFER TO A MODEL 242 TRANSFER."



"THE KIT CONTAINS A TRANSFER, NSN 2520-01-409-2512, TWO PROP SHAFTS AND ALL NEEDED HARDWARE."

"IT IS DESIGNED TO BE USED ONCE PER VEHICLE. ONCE THE KIT IS INSTALLED, ORDER THE -2512 TRANSFER WHEN A REPLACEMENT IS NEEDED."

THE MODEL 218 TRANSFER IS NO LONGER BEING BOUGHT. IT IS AVAILABLE IN **SMALL QUANTITIES** FROM A TACOM REBUILD PROGRAM.

IF YOU NEED ONE OR TWO 218s, ORDER THEM OR THE -0822 KITS. IF YOU NEED MORE, ORDER JUST THE KITS.

"A1-SERIES HUMMVVS AND ALL THE M1097s USE A MODEL 242 TRANSFER, NSN 2520-01-452-8365, THAT IS **DIFFERENT FROM** AND **NOT COMPATIBLE** WITH THE MODEL 242 USED ON A2-SERIES TRUCKS, NSN 2520-01-409-2512."

Model 242 transfer

